INSTALLATION INSTRUCTIONS

CEILING-MOUNTED SHOWERHEAD

頂噴安裝說明



- ▲Water Outlet should be flush with finished surface of ceiling. 出水接頭建議與天花板完成牆面持平。
- 1. Remove **Outer Cover**, and let the threaded tube go through the **Fixing Bracket**. 請先將頂噴外罩拿開,接著將牙管的部份穿過固定座。
- 2. Thread the tube into **Water Outlet**, and use **Fixing Bracket** as template to mark the drilling positions on ceiling. 將牙管鎖入天花板的出水接頭中,再利用固定座的圓孔做出記號。
- Avoiding the water pipe as drilling holes for fixture.
 - 鑽孔位置切勿與預埋管線重疊避免後續施工造成管路破損。
- 3. Disassemble the **Showerhead**. Fix the **Fixing Bracket** with **Stainless Steel Anchors**. Cover the **Outer cover** to **Showerhead**. 將頂噴拆下,螺絲將固定座固定。接著再將頂噴重新穿過頂噴外罩。
- 4. Apply pipe compound or thread sealant tape to the thread of tube end, screw it into **Water Outlet**, and then screw the **Outer Cover** to **Fixing Bracket** to complete the installation.

將牙管接頭1/2"牙塗上管牙膠或包覆止洩帶,穿過固定座後再鎖入牆壁出水口,再將外殼鎖上固定座即完成安裝。

FIXING CONTENTS

組配件內容



JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD. www.justime.com [000] 190219] PU67-77-STAS 「 MADE IN TAIWAN