MOUNTING INSTRUCTIONS

6860 安裝 說 明

- **1.)** To locate appropriate drilling centers with pencil. 使用鉛筆在預定鑽孔的位置,畫上記號.
- Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**.
 當安裝在水泥牆,使用1/4英吋鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平於 牆面.
- 3.) Attach **Main Body** to wall with **Wall Screws**. 將產品本體以螺絲鎖在牆面上.
- **4.)** Secure the **Decorative Cover** over **Main Body** to finish. 將裝飾蓋套上產品本體即完成安裝程序.





210708

PU68-60-ST00 MADE IN TAIWAN

JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD. www.justime.com