## **INSTALLATION INSTRUCTIONS**

## 6880安裝說明

- **1.** Loosen the **Set Screw** and disassemble the components for installation. 用隨附的六角扳手將埋頭螺絲鬆開,使主體與底座分離。
- 2. Use **Mounting Base** as template to locate appropriate drilling centers with pencil.

用底座為樣板用鉛筆點繪出要鑽孔的位置。

- 3. Drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**. 水泥牆在鑽孔後須使用隨附的塑膠塞。
- 4. Attach Mounting Base to wall with Wall Screws. 將底座鎖在牆上,並確認已完全固定。
- 5. Press the **Main Part** tightly over the center stem showing on **Mounting Base** and secure with **Hexagon Key**. 本 L 主题,可用于在相关的细菌网络的原,它式内脏。

套上主體,再用六角扳手將埋頭螺絲鎖緊,完成安裝。





JUSTIME IS時代 ST SHENG TAI BRASSWARE CO., LTD.